




1




2







1








2







1




2




1








2







2x

30 66 5070




2x






30 66 5000



30 66 5080









30 06 9550



30 00 4260

2x 30 09 4630



2x 30 00 6330

2x 30 09 4620



2x 30 00 6350

30 63 1270



30 00 6340

30 63 5370




30 00 7260

30 63 5370



30 09 0230

30 14 1150



30 62 6430



2x 30 21 0430



30 07 4440



30 62 0370



30 63 5320



30 63 5180



30 09 4320



2x 30 03 0720

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-beel