


playmobil®
3191



 **WARNING:**
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !




1








2




3



1




2




3




4




1



2



30 04 0240



30 88 4120

30 24 2730



2x 30 06 8070



30 00 0822

30 61 1370

30 62 3342



2x 30 24 2720



30 00 0832




30 61 0890




30 51 2590



30 24 2800




30 03 6060




30 83 0300



30 89 3462



30 24 2780



30 24 2770




30 07 5210



30 07 5250



30 89 8170



30 04 7650



30 06 5200



4x 30 07 5310




8x 30 24 1750



30 07 5240



30 07 5230



Serviceadressen finden Sie in
allen Playmobil-Prospekten

Addresses of Customer Service
Departments are shown in all
Playmobil catalogues

L'adresse du service
consommateurs est indiquée
dans tous les catalogues
Playmobil

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de
Servicio al Consumidor se encuentran
en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
Εξυπηρέτησης Πελατών
είναι καταχωρημένη σε όλους
τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl