

playmobil®

3230



WARNING: CHOKING HAZARD






Contains a small ball and small parts.
Not for children under 3 years.



"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!




1






1



2





4


3x




3x




1




2





1







7




1




2




1






2




1





2




2x




2x




30 23 2310




30 22 0340



30 23 7772



30 23 2170





30 00 9940




30 14 1980




30 10 1440




30 11 0970




30 23 2190




30 23 2200




30 23 2250




2x 30 22 5860




30 23 2260



30 45 3640




30 45 3630




30 23 2220




2x 30 23 2300




3x 30 23 2210




30 23 2230



30 21 3013



8x 30 23 2160



30 23 2280



30 04 1630



30 28 8830




3x 30 04 2980



3x 30 08 5670




3x 30 20 4720



30 89 9420




30 89 9300



30 23 2290



4x 30 66 0160



30 60 0030



30 23 2240



30 06 7770



30 62 5750



30 62 5740



30 05 7710



2x 30 09 3840



30 22 0560



30 22 0570



6x 30 06 7780



30 09 6610



30 08 5750



4x 30 06 7550




30 51 0590




30 51 6832




30 65 8820




32x 30 09 6900



16x 30 03 6600



16x 30 09 4650



16x 30 05 9720

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten
Addresses of Customer Service Depart-
ments are shown in all PLAYMOBIL
catalogues

L'adresse du service consommateurs
est indiquée dans tous les catalogues
PLAYMOBIL

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u
het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran
en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης
Καταναλωτών PLAYMOBIL βρίσκεται σε
όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēl

Abbildungen können vom Original abweichen. / Product may differ from image shown.
Les illustrations peuvent différer de l'original. / Afbeeldingen kunnen verschillen van het werkelijke artikel.

© 2002 geobra Brandstätter Stiftung & Co KG

Brandstätterstr. 2-10
90513 Zirndorf, Germany.
No. 30 89 9410 08.19



www.playmobil.com