









1



2


1

30 05 9300




2


30 04 8770





30 06 2590







30 23 1370










30 06 3040



3








6



4x








30 06 7620





7



















1













2x

1

2





Serviceadressen finden Sie in
 allen Playmobil-Prospekten

Addresses of Customer Service
 Departments are shown in all
 Playmobil catalogues

L'adresse du service
 consommateurs est indiquée
 dans tous les catalogues
 Playmobil

Troverete gli indirizzi dei centri di
 assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de
 Servicio al Consumidor se encuentran
 en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
 Εξυπηρέτησης Πελατών
 είναι καταχωρημένη σε όλους
 τους καταλόγους Playmobil
 pronounce: plāy-mō-bēēl