









1




2




3




4




1



2




30 03 385




30 03 238

1




2



3




30 03 235




30 03 234


1



2







3





30 88 559







1



2









3













4

2x









30 64 676



30 00 733

30 03 425




30 13 053


30 06 809




30 00 732



30 61 000




30 65 058





30 61 240



30 03 399



30 64 739



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil
pronounce: play-mo-beel