

playmobil®

4093


Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!




WARNING:
CHOKING HAZARD

Small parts. Not for children under 3 years.




"Ne concerne que les USA"






1






2







3






4




5








6







7












9



















11































1




2












30 22 7190




2x 30 28 6870




30 65 4282




2x 30 28 5030




2x 30 26 9140




30 21 2740




30 22 7140



30 21 4460



30 22 7130




30 23 9360




30 28 5100




3x 30 28 5050




30 28 6560



30 28 6880




30 65 4262



30 51 1660



10x 30 28 5040




2x 30 22 1350




30 80 5662




30 61 6440




2x 30 26 9150




2x 30 65 4272




5x 30 23 9380




5x 30 23 8190




4x 30 25 1080



14x 30 23 8180



2x 30 22 7520



30 28 6550



30 26 9620



30 09 6060



30 65 2250




30 62 3762




30 63 4562



2x 30 67 0392



30 21 1730




30 66 0800



30 26 9630



4x 30 03 5990



3x 30 07 7860



2x 30 23 8830



2x 30 04 1630



3x 30 03 2900



30 23 6160



30 28 6540



3x 30 28 5110



30 07 0520



30 02 6890



2x 30 22 0920



2x 30 20 4710



30 67 5520



30 67 5530



30 66 5830



30 83 0070



30 83 0370



30 66 7350



4x 30 28 5060




2x 30 20 4720



30 65 0182



30 02 7120



2x 30 51 2510



30 46 7680



30 46 7690



2x 30 63 5562



2x 30 23 8580



30 08 9082



2x 30 22 5800



30 26 9650



4x 30 26 9530



2x 30 09 6830



30 24 2452



30 64 0804



2x 30 02 7130



10x 30 23 8200



4x 30 22 2740



8x 30 20 9950



80x 30 09 6900



48x 30 03 6600

Serviceadressen finden Sie in allen Playmobil-Prospekten	In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.
Addresses of Customer Service Departments are shown in all Playmobil catalogues	Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil
L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil	Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.
Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil	pronounce: plāy-mō-bēēl

