

playmobil®
4327






WARNING:
CHOKING HAZARD

Small parts. Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !
Belangrijke documenten, bewaar deze zorgvuldig!






30 81 3352




30 26 7410




30 22 7110



30 20 0272



30 20 0262



30 23 1000

30 27 3120




30 25 9960




30 00 6412



30 10 2410




30 60 9090




30 51 2580




30 07 5710



30 65 0580



30 28 5250



30 24 3830



30 66 2160



30 89 5442



30 20 0222



3x 30 63 3042

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl