


playmobil®
4439


⚠ **WARNING:**
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.

"Ne concerne que les USA"


Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !




1




2




3



4





30 09 9400






5

2x



6





30 03 0730


30 88 4110

30 23 7230



30 07 6930


30 07 7820



2x 30 07 6390



30 24 7300



30 62 6822



30 62 6752



2x 30 62 6782



30 24 8380



30 07 6410



2x 30 07 6420



30 22 8890



30 05 7380

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl