


playmobil®
4484





WARNING:
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.

"Ne concerne que les USA"




Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !



1




2



3



2x





2x




2x




4




1





2





3




1




2




1



2


























1



2













30 88 2532




30 89 8012




30 89 8042




30 61 2360




30 25 3200




30 03 2480



30 03 2470




30 25 3190




30 25 0810



2x 30 25 0800



30 61 2470



30 61 2460



30 62 3140



30 62 7802



2x 30 25 2870




30 22 8600



30 25 3180



30 25 3130



2x 30 03 6610



2x 30 21 0670



2x 30 25 3220



2x 30 25 2840



2x 30 25 2850



30 25 3150



30 22 8640



2x 30 25 2920



30 25 2960



30 25 2950



30 25 2930



30 25 2940



30 25 2900



30 25 2910



30 25 3160



30 25 3170



30 08 5750



30 25 3140



4x 30 25 3230



2x 30 24 1910



30 25 3030



2x 30 21 0700



4x 30 25 3020



6x 30 05 7420



30 20 5540



30 20 4700



30 20 5550



3x 30 20 4710



30 09 2110



2x 30 20 4720



2x 30 25 0030



30 25 2970



30 25 2980



2x 30 25 3000



4x 30 25 2990



3x 30 25 0610



4x 30 25 3110



2x 30 25 3120



3x 30 25 3100



6x 30 09 4650



6x 30 25 2360



2x 30 24 9230



2x 30 24 9829




2x 30 05 9729



3x 30 05 8709



30 25 0710



30 25 0000



30 25 3040



30 25 0720



30 25 3050



30 25 3060



6x 30 20 3920



3x 30 20 4460



3x 30 25 3070



2x 30 23 8530



30 02 6840



8x 30 25 3090



8x 30 06 0930



6x 30 25 3080



2x 30 25 2830



2x 30 25 2820



6x 30 25 2810



30 66 7350



16x 30 09 6900



8x 30 03 6600

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil
pronounce: plāy-mō-bēēl