


playmobil®

5007





WARNING:
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.



"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !
Belangrijke documenten, bewaar deze zorgvuldig!













1














3








6




1




© 2009 geobra Brandstätter
D-90511 Zirndorf 07.09
No. 3081622


2




3



2x




3 **4**








5

8 **7**






6










1






6

1








3





1




2



1




2




30 89 1152


1



2



30 22 7510













30 07 3840


30 08 1270

30 07 3840


30 07 3820

30 61 7700







30 22 7210




2x 30 22 7220




30 22 7430




30 22 7420



30 22 7240




30 22 7370




30 67 2730




30 24 1540



30 67 2740




30 62 3600




4x 30 22 7140




30 62 3052



2x 30 22 7400




30 89 8980




30 22 7130




30 89 7230




30 20 7392




30 64 8532



30 22 6990




2x 30 65 9012




30 88 3262




30 81 6222



2x 30 66 7780




4x 30 05 4490



30 20 7382




2x 30 06 7620




30 20 7402



30 20 7332



30 20 7482




30 20 7452




2x 30 20 5380




2x 30 20 7352



2x 30 20 0160




30 51 6830



30 21 1830




30 21 1840



30 21 1850



2x 30 22 7080



2x 30 22 7380



2x 30 03 2340



2x 30 03 4650



30 24 1550



4x 30 22 6970




4x 30 82 4140




2x 30 22 6960



2x 30 82 0980



30 02 2730



30 03 3550



2x 30 20 5540



30 23 7910



30 26 8020



30 26 8010



2x 30 20 7362



2x 30 20 7372



30 03 2940



2x 30 22 7480



30 64 7940



30 81 6420



30 20 0350



2x 30 26 8000



30 22 7100



10x 30 22 7000



4x 30 20 7342



5x 30 22 7180



30 03 2450



30 03 4630



30 23 7730



2x 30 03 2920



2x 30 23 8420



2x 30 20 5550



2x 30 26 8030



30 24 9210



30 03 0720



3x 30 22 7110



4x 30 03 1150



30 20 9950



30 65 8822



64x 30 09 6900



48x 30 03 6600



30 20 0200






3x 30 20 7472



4x 30 25 2820



4x 30 25 2810



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl