


playmobil®

5632
5677

1



30 82 8193

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important: Please keep these instructions for future reference !
Documents importants, à conserver soigneusement !
Belangrijke documenten, bewaar deze zorgvuldig !



WARNING:
CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"



2



30 24 8980

30 21 1142



30 51 4562

3

4x

1



30 25 9873


30 82 4690

30 20 6502

2



30 28 0210




30 23 8903

2.


1.





30 23 2560

4



30 51 4732





2x



2x



2x



2x



30 51 4722

30 23 7893



30 22 5760



30 00 5683



30 00 5693



30 24 3830



30 25 5830



30 09 6830




30 23 8953



30 23 8943



4x 30 23 5270



30 23 8893

30 64 4934

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl



© 2014 geobra Brandstätter Stiftung & Co.KG
Brandstätterstr. 2-10
90513 Zirndorf, Germany.
No. 30 82 8913 01.16

www.playmobil.com