




3955
5711

WARNING:
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.


"Ne concerne que les USA"



30 63 4700



30 91 7440



30 08 7780

30 08 7770

30 08 7750




30 91 7470



30 03 2630



30 91 7450



30 20 1650

30 80 5410

30 20 1160



30 91 7480



30 21 1250

30 02 9360



30 91 7460



30 11 1010



30 91 7490

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !

30 23 5750




30 03 1950



30 91 7500

30 06 0020




30 91 7510

30 06 7290



30 66 0770



30 91 7520



30 10 1520



30 06 7680




2x 30 06 7700



30 46 1370




2x 30 46 1380



2x 30 46 1430




30 23 5760







30 91 7530





30 91 7540






30 91 7550



1





2



30 91 7610


2x 30 06 6840



2x 30 06 6850



30 89 9810



30 91 7620

30 21 1090



30 21 1080



2x 30 21 9930



30 02 2340



30 89 4780



30 20 8450



30 88 9090



30 91 7640

30 22 8600



30 22 8640



30 91 7650



30 67 0950



30 91 7660

30 22 7770



2x 30 22 7700




30 13 0650



30 91 7670

30 91 7700







Serviceadressen finden Sie in
allen Playmobil-Prospekten

Addresses of Customer Service
Departments are shown in all
Playmobil catalogues

L'adresse du service
consommateurs est indiquée
dans tous les catalogues
Playmobil

Troverete gli indirizzi dei centri
di assistenza in tutti i cataloghi
Playmobil

Las Direcciones de los
Departamentos de Servicio al
Consumidor se encuentran en
todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
Εξυπηρέτησης Πελατών
είναι καταχωρημένη σε όλους
τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl