

**playmobil®**  
6226





**WARNING:**  
**CHOKING HAZARD**

Small parts. Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !  
Important: Please keep these instructions for future reference !  
Documents importants, à conserver soigneusement !  
Belangrijke documenten, bewaar deze zorgvuldig !




[www.playmobil.com](http://www.playmobil.com)

1



30 61 7800

2





30 63 0552

30 26 1920

30 26 1940

3

30 26 1930



30 61 1130




30 12 0390




30 12 0200




30 23 5220



30 09 0520



30 26 9510



30 21 0093



30 23 5320



30 06 5640



30 23 1330



30 24 4130



30 25 9070



30 21 7390



30 24 3770



30 25 6690



30 21 4530



2x 30 26 9530



30 24 2442



30 24 2472

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

© 2013 geobra Brandstätter GmbH & Co.KG  
Brandstätterstr. 2-10  
90513 Zirndorf, Germany.  
No. 30 80 0613 12.13