

**playmobil®**

6521




**WARNING:**  
**CHOKING HAZARD**

Small parts. Not for children under 3 years.



"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !  
Important: Please keep these instructions for future reference !  
Documents importants, à conserver soigneusement !  
Belangrijke documenten, bewaar deze zorgvuldig !

1






2






30 51 1962



[www.playmobil.com](http://www.playmobil.com)





30 61 0132



30 51 0952



30 51 6882



30 04 2142



30 25 3892



30 04 2212



30 88 0102



30 09 6780



30 28 7180



2x 30 09 3780



30 09 6830



30 22 5460



30 05 8570



30 06 0040



2x 30 06 7550



30 09 6810



30 20 9040

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

© 2016 geobra Brandstätter Stiftung & Co.KG  
Brandstätterstr. 2-10  
90513 Zirndorf, Germany.  
No. 30 80 5924 06.16