

**playmobil®**

6849  
9157




Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!

 **WARNING:**  
**CHOKING HAZARD**  
Small parts. Not for children under 3 years.

"Ne concerne que les USA"







1












# 2





3







4









5





6










7



8













10









3x 30 22 5859



3x 30 25 1270



30 12 0350



30 80 9633



30 03 5652



30 03 6022




30 03 6012





30 03 5882



30 82 7224



30 03 5802



30 03 7952




30 03 5812




30 03 5702



30 22 9202



30 03 7962



30 03 5692



30 03 7972



30 21 4912



2x 30 03 5892



2x 30 28 6850



2x 30 20 6790



3x 30 66 7780



30 66 7640



3x 30 05 4490



30 23 8142



30 03 5922



30 22 9252



30 62 1095



30 26 1700



30 03 5482



2x 30 62 0935



30 03 5842



30 65 4093



2x 30 03 5832



30 03 5772



30 03 5752



2x 30 03 5762



30 03 7932



30 03 5572



30 03 5682



30 62 1055



30 25 9003



30 22 8852



30 03 5612



30 03 5622



30 03 5862



30 03 5952



30 03 5642



30 03 5732



30 22 9312



30 22 9302



30 03 7942



30 03 5942



30 24 8370



30 62 1045



30 20 9450



30 82 7214



30 46 2852



30 46 2512



12x 30 05 0312



30 03 5712



30 25 6820



30 03 5932



30 26 1710



30 03 5472



30 22 9282



30 27 4780



2x 30 05 8550



30 03 5742



2x 30 23 3752



30 22 9462



30 23 5183



30 60 1692



2x 30 25 3100



3x 30 06 2499



30 27 7830



2x 30 27 7840



30 27 7850



7x 30 25 5502



30 03 5582



30 03 3282



2x 30 03 3312



30 03 5592



6x 30 03 5902



3x 30 22 9262




2x 30 22 9272



40x 30 09 6900



49x 30 03 6600



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl



© 2016 geobra Brandstätter Stiftung & Co. KG  
 Brandstätterstr. 2-10  
 90513 Zirndorf, Germany.  
 No. 30 80 7044 10.16

6849 + 6518

9157 + 6518



6849 + 6519

9157 + 6519

