

30 67 0263

2x 30 23 3562



35 27 9380



30 63 0534



30 03 3142



30 82 8384



30 82 8364



30 23 4602

30 23 0102

30 11 3340

30 22 2652

30 03 3132

30 82 8374



30 20 6792



30 21 3363

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service Depart-
ments are shown in all PLAYMOBIL
catalogues

L'adresse du service consommateurs
est indiquée dans tous les catalogues
PLAYMOBIL

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u
het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran
en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης
Καταναλωτών PLAYMOBIL βρίσκεται σε
όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēel

© 2016 geobra Brandstätter Stiftung & Co.KG
Brandstätterstr. 2-10
90513 Zimdorf, Germany.
No. 30 82 8394 07.20

Abbildungen können vom Original abweichen. / Product may differ from image shown.

Les illustrations peuvent différer de l'original. / Afbeeldingen kunnen verschillen van het werkelijke artikel.

playmobil
6852




WARNING:
CHOKING HAZARD
Small parts. Not for children under 3 years.


Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!

"Ne concerne que les USA"

1



2



www.playmobil.com

1