

playmobil®

CITY
ACTION



6878/6924



WARNING: CHOKING HAZARD




Small parts. Not for children under 3 years.

“Ne concerne que les USA“



Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

UK-Importer:
Playmobil UK Ltd.
Regency House
1 Miles Gray Road
Basildon
Essex
SS14 3RW
UK



30 82 3444



1



30 51 6790

2



30 61 5580



30 03 5370



1




2




30 64 1352

30 23 1843



30 65 0222

30 64 8444



30 28 3800


30 63 7610

30 20 3040

5



30 02 8852



30 02 8792



30 09 4020

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service Depart-
ments are shown in all PLAYMOBIL
catalogues

L'adresse du service consommateurs
est indiquée dans tous les catalogues
PLAYMOBIL

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u
het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran
en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης
Καταναλωτών PLAYMOBIL βρίσκεται σε
όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-beēl



2x 30 23 6832



30 62 0370




30 64 8454



3x 30 22 6530



30 03 4630



30 02 8802



30 03 4940



30 09 4750



30 26 3080



● 70570



● 70669



● 70670



● 70568



● 70573



● 70577



● 70572



● 70575



● 70569



● 70571

