

playmobil®
6929



WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important: Please keep these instructions for future reference !
Documents importants, à conserver soigneusement !
Belangrijke documenten, bewaar deze zorgvuldig !



Serviceadressen finden Sie in
allen Playmobil-Prospekten

Addresses of Customer Service
Departments are shown in all
Playmobil catalogues

L'adresse du service
consommateurs est indiquée
dans tous les catalogues
Playmobil

Troverete gli indirizzi dei centri
di assistenza in tutti i cataloghi
Playmobil

In alle PLAYMOBIL catalogi
vindt u het adres van onze
klantendienst.

Las Direcciones de los
Departamentos de Servicio al
Consumidor se encuentran en
todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
Εξυπηρέτησης Καταναλωτών
PLAYMOBIL βρίσκεται σε όλους
τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl


1



2




1




2






3






4





5




6




7




8



9







(D A CH L B) Nur Trinkwasser verwenden. Nach dem Spielen austrocknen lassen.

(USA GB CDN M IRL) Use only tap water. Dry thoroughly after play.

(F CDN B L CH) N'utiliser que de l'eau potable. Faire sécher après chaque utilisation.

(E MEX) Utilizar solamente agua potable. Dejar secar antes de guardar.

(NL B) Enkel drinkbaar water gebruiken. Na het spelen laten drogen.

(I CH) Usare solo acqua potabile. Asciugare bene dopo ogni uso.

(P) Utilizar somente água potável. Deixar secar antes de guardar.

(DK) Anvend kun drikkevand. Lad det tørre ud når du er færdig med at lege.

(N) Kun drikkevann skal benyttes. Tørk opp etter at leken er ferdig.

(S FIN) Använd endast dricksvatten. Låt torka efter användandet.

(FIN) Käytä ainoastaan juomavettä. Anna kuivua leikin jälkeen.

(H) Kérjük kizárólag ivóvizet használgjon! Játék után ajánlott a termék kiszáritása!

(CZ) Používat jen pitnou vodu. Po hraní nechat vyschnout.

(EST) Kasutada üksnes joogivett! Mängimise järel kuivatada!

(LV) Izmantot tikai dzeramo ūdeni. Pēc spēlēšanās ļaut nožūt.

(LT) Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.

(SLO) V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.

(SK) Používať iba pitnú vodu. Po hre nechať vyschnúť.

(PL) Używaj tylko wody pitnej. Po zabawie pozostaw do wyschnięcia.

(TR CY) Sadece içme suyu kullanınız. Oyundan sonra kurumaya bırakın.

(GR CY) Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.

(RO) Se folosește doar apă potabilă. După joacă se lasă să se usuce.

(BG) Използвайте само питейна вода. След игра оставете да изсъхне.

(HR) Koristiti samo pitku vodu. Poslije igranja pustiti da se osuši.

(CN) 仅使用饮用水。玩耍后要干燥。



30 05 6602



30 05 6592



30 05 6582



30 80 2433



30 63 2135



30 23 9382

30 88 7672



30 22 0562



30 63 5583



30 05 6622

30 056612

30 22 2120



3

30 22 0880

4



30 29 0470



30 23 3322



30 82 2642



2x 30 89 4680



30 00 0604



30 82 6614



2x 30 05 6742



2x 30 24 0172



30 80 6534



30 28 2500



30 05 6782



30 21 4263




30 29 9730




30 89 4940



30 24 9800



30 60 6610



30 05 6632



30 05 6702



30 05 6662



30 05 6772



2x 30 05 6672



30 05 6682




30 05 6692



30 05 6712



30 05 6642



30 05 6652



30 80 6823



30 88 8852



30 27 6090



30 51 8530



30 05 6752



2x 30 05 6732



2x 30 05 6722



2x 30 05 6792



30 65 8822



30 05 6222



30 22 2740



30 27 6120



30 29 2960



5x 30 03 6600



4x 30 09 6900



30 23 0460




30 21 4793



2x 30 25 2830



2x 30 25 2810



30 51 6122

© 2017 geobra Brandstätter Stiftung & Co. KG
Brandstätterstr. 2-10
90513 Zirndorf, Germany.
No. 30 80 7864 04.17



www.playmobil.com