

playmobil®


70121

 **WARNING:**
CHOKING HAZARD
Small parts. Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!






30 51 3470



30 03 2753

30 09 0650







30 82 0535



(DE) (AT) (CH) (LU) (BE) repositionierbar
 (US) (GB) (CA) (MT) (IE) repositionable
 (FR) (CA) (BE) (LU) (CH) repositionnable
 (ES) (MX) reposicionable
 (NL) (BE) herpositioneerbaar
 (IT) (CH) riposizionabile



30 82 0525




30 14 1792



30 14 0159



30 03 2743



30 04 3212




3x 30 02 5040



30 03 4680



30 24 3830



30 22 0570



2x 30 06 1790




2x 30 24 9122




4x 30 22 0510



3x 30 21 3492



30 51 9390



30 51 6330

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

Abbildungen können vom Original abweichen. / Product may differ from image shown.
 Les illustrations peuvent différer de l'original. / Afbeeldingen kunnen verschillen van het werkelijke artikel.

