

playmobil®

Country



70325





WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.



”Ne concerne que les USA“

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!



1





2





3






1






2




1




2






3




1




2




4








5










6





7





30 63 3123



30 14 9920

30 06 5293



30 14 9910

30 06 5313




30 10 3690


30 06 5303



30 11 3240




30 82 7005



30 65 7614



30 65 7624




30 23 9212



30 23 4050




30 08 5950



30 06 5413



30 27 6910




30 06 5433



30 20 4412




2x 30 27 4590



30 64 1666



30 21 9602



30 06 5443



30 22 9713



30 22 2812



30 06 5453



4x 30 20 9663



4x 30 22 6120



4x 30 82 2990



4x 30 82 3570



4x 30 28 3570




4x 30 06 3512



8x 30 23 4722



30 08 5960



30 06 5423



2x 30 22 4143



30 06 5483



30 06 5493



30 02 7392



6x 30 02 7382




2x 30 02 7372



30 05 6222




3x 30 06 0192



3x 30 02 7402



30 02 7522



4x 30 21 4953



30 65 8822



30 09 6060



30 63 3113



30 27 4760



30 09 9190



2x 30 25 6010



2x 30 02 7412



30 02 7422



30 23 4953



30 22 6150



30 26 7680



30 09 7472



2x 30 21 0570



30 88 0582



30 25 0543



2x 30 28 7910



7x 30 02 7432



2x 30 02 7442




10x 30 09 6900




10x 30 03 6600



30 61 1542



30 51 5342



30 51 4570

Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten
Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze Klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēil



© 2020 geobra Brandstätter Stiftung & Co.KG

Brandstätterstr. 2-10

90513 Zirndorf, Germany.

No. 30 80 0416 06.20

www.playmobil.com