

playmobil®

70337



WARNING:
CHOKING HAZARD



Small parts. Not for children under 3 years.

"Ne concerne que les USA"





Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!







1





2






3







4




5







6




7






8.1





8.2




2x



9




1




2




1




2




1



2



1




2




4x



30 25 8720



30 03 4862




30 21 9213

4x




30 25 2830




6


30 24 8052






1



2





30 09 5940




30 82 6395


3x




2x



3x




1



2x



2



30 63 4293



30 04 0600



30 21 1383



30 24 0362



30 20 6212



2x 30 22 0772



30 00 1153

30 14 2872

30 14 2882


30 14 2862




30 05 5113




30 51 0532




30 05 5123




30 63 6026



30 05 5073



30 03 9703



30 05 5083




7x 30 24 0442



2x 30 24 1292




4x 30 24 1282



30 03 9693



2x 30 24 1302



30 04 3683



30 82 0153



30 82 6385



Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten
 Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues
 L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL
 Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL
 In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.
 Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL
 Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.
 pronounced: plāy-mō-bēēl

Abbildungen können vom Original abweichen. / Product may differ from image shown.
 Les illustrations peuvent différer de l'original. / Afbeeldingen kunnen verschillen van het werkelijke artikel.

© 2019 geobra Brandstätter Stiftung & Co.KG
 Brandstätterstr. 2-10
 90513 Zimndorf, Germany.
 No. 30 82 7625 07.19



www.playmobil.com