

playmobil®

CITY
ACTION



70592



WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service Depart-
ments are shown in all PLAYMOBIL
catalogues

L'adresse du service consommateurs
est indiquée dans tous les catalogues
PLAYMOBIL

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u
het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran
en todos los catálogos PLAYMOBIL


Η διεύθυνση του Γραφείου Εξυπηρέτησης
Καταναλωτών PLAYMOBIL βρίσκεται σε
όλους τους καταλόγους PLAYMOBIL.

pronounced: pläy-mō-bēē

1





30 80 4556



2

2x

30 09 3583



30 09 3533

1

30 09 3693



30 05 0672



30 09 2163



2

1

30 22 1723




2

30 20 9113




30 09 3753





(DE) (AT) (CH) (LU) (BE) repositionierbar
 (US) (GB) (CA) (MT) (IE) repositionable
 (FR) (CA) (BE) (LU) (CH) repositionnable
 (ES) (MX) repositionable
 (NL) (BE) herpositioneerbaar
 (IT) (CH) riposizionabile



30 80 4566

30 21 5063




30 04 8552




30 09 3633



30 09 3383



30 22 4433



3

30 08 6303

30 09 3653



30 09 3643



30 11 4610

30 09 3123

30 09 3733



30 08 5583

30 11 4570



30 61 1992

30 09 3773




30 61 1672

30 25 3393



30 08 0703




30 14 3912



30 61 2002



30 14 3932



30 80 4576



30 09 3593



30 09 3603



30 08 2203



30 09 3703



30 09 3713



30 09 3723



30 09 3763



30 09 3743



30 62 5547



30 23 8652



30 29 7120



30 09 3613



30 09 3623



30 61 7130



30 60 7802



30 09 3673



30 09 3683



30 09 3663



30 07 0620



2x 30 08 5573



2x 30 05 3833



2x 30 04 5763

70592 + 70590 + 70591



70591

70590

70592



70591



70596



70595



70594



70590



70592



70593

