

playmobil®

SPORTS
& ACTION



71125



WARNING: CHOKING HAZARD

Contains a small ball and small parts.
Not for children under 3 years.

"Ne concerne que les USA"


Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.


UK-Importer:
Playmobil UK Ltd.
Regency House
1 Miles Gray Road
Basildon
Essex
SS14 3RW
UK

UK
CA


1



30 00 2555



30 80 1460




30 88 5832

2



30 06 6654

3



30 03 9264

DE AT CH LU BE ACHTUNG!

Nicht auf Augen oder Gesicht zielen.

US GB CA MT IE WARNING!

Do not aim at eyes or face.

FR CA BE LU CH ATTENTION!

Ne pas viser les yeux ou le visage

ES MX ¡ADVERTENCIA!

No apuntar a los ojos ni a la cara.

NL BE WAARSCHUWING!

Niet op ogen of gezicht richten.

IT CH AVVERTENZA!

Non mirare agli occhi o al viso.

PT ATENÇÃO!

Não apontar para os olhos ou face.

DK ADVARSEL!

Sigt ikke mod øjne eller ansigt.

NO ADVARSEL!

Sikt ikke på ansikt eller øyne.

SE FI VARNING!

Sikta inte mot ögon eller ansikte.

FI VAROITUS!

Ei saa kohdistaa suoraan silmiin tai kasvoihin.

HU FIGYELMEZTETÉS.

Tilos szemre vagy arcra célozni.

CZ UPOZORNĚNÍ!

Nemířte na oči nebo na obličej!

EE HOIATUS!

Ära sihi silmadesse ega näkku.

LV BRĪDINĀJUMS!

Nevērst pret acīm vai seju.

LT ĮSPĖJIMAS!

Netaikyti į akis arba veidą.

SI OPOZORILO!

Ne merite v oči ali obraz.

SK UPOZORNENIE!

Nemieriť do očí alebo do tváre.

PL OSTRZEŻENIE!

Nie celować w oczy i twarz.

TR CY DİKKAT!

Göze veya yüze doğru tutmayınız.

GR CY Προειδοποίηση!

Μη μην γίνεται στόχευση στα μάτια ή στο πρόσωπο.

RO AVERTISMENT!

Nu se țintește în ochi sau în față.

BG Внимание!

Не насочвайте към очите и лицето.

HR UPOZORENJE!

Ne ciljati u oči ili lice.

RU Внимание!

Не цельтесь в глаза или лицо.

CN 警告!

请勿瞄准眼睛或脸。



30 81 9946



30 09 6610

Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēēl



71120



©2022 geobra Brandstätter Stiftung & Co. KG • Brandstätterstr. 2-10
90513 Zirndorf, Germany • No. 30 80 3794

04.22

