








1












2x

30 25 3020


30 25 3010




3




1



4




2




6



1



2

















1



2

3x







30 25 3130



30 25 3150



30 25 2950



30 25 0030



30 25 2970



30 25 3120



30 08 5750



30 25 3140



30 25 3030



3x 30 20 3920



3x 30 25 3080



3x 30 06 0930

Serviceadressen finden Sie in
allen Playmobil-Prospekten

Addresses of Customer Service
Departments are shown in all
Playmobil catalogues

L'adresse du service
consommateurs est indiquée
dans tous les catalogues
Playmobil

Troverete gli indirizzi dei centri
di assistenza in tutti i cataloghi
Playmobil

In alle PLAYMOBIL catalogi vindt
u het adres van onze
klantendienst.

Las Direcciones de los
Departamentos de Servicio al
Consumidor se encuentran en
todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
Εξυπηρέτησεως Πελατών
είναι καταχωρημένη σε όλους
τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl