











WARNING:
CHOKING HAZARD - SMALL PARTS.
Not for children under 3 years.

"Ne concerne que les USA"



4





30 02 684



30 02 682

30 02 684



30 02 683



30 07 642



30 02 686

30 02 698



30 14 105



30 02 697



30 09 178

30 02 687



30 06 399



30 00 710



30 02 696



30 66 594



30 66 047



30 66 046



30 02 664



30 63 436



30 60 942



30 60 514



30 66 552



30 66 553



30 09 632

Serviceadressen finden Sie in
allen Playmobil-Prospekten

Addresses of Customer Service
Departments are shown in all
Playmobil catalogues

L' adresse du service
consommateurs est indiquée
dans tous les catalogues
Playmobil

Troverete gli indirizzi dei centri
di assistenza in tutti i cataloghi
Playmobil

Las Direcciones de los
Departamentos de Servicio
al Consumidor se encuentran
en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου
Εξυπηρέτησεως Πελατών
είναι καταχωρημένη σε όλους
τους καταλόγους Playmobil.