







1




2





30 63 5670




30 03 8000



1



2



30 88 6780

30 03 8570



30 03 8130

30 03 8600



30 03 9190



30 06 7780






30 07 5710

1

2x




2











30 03 2210



1





2









Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil
pronounce: play-mo-beeΓ