

playmobil®

CITY
ACTION



70446

1

2x



WARNING:
CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!


Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

30 07 7040





30 64 0936

2



3





ASSEMBLY INSTRUCTION





1



2







3



4

ASSEMBLY INSTRUCTION





30 64 0866



30 64 0896



30 64 3466



30 07 0992



30 00 7164




30 00 7174



30 00 7184





2x 30 03 5650



30 09 7020



30 66 1330



2x 30 21 4880



30 23 9480



30 67 9992



30 06 4983



30 64 0906



30 21 6100



30 51 2352



Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: pläy-mō-bēil





+ 70443



oder
or
ou





70446



70444



70443



70445



70442



70441

©2020 geobra Brandstätter Stiftung & Co. KG • Brandstätterstr. 2-10 • 90513 Zimzdorf, Germany
04.20
No. 30 80 1896

