

playmobil®

Princess



70448





# WARNING: CHOKING HAZARD




Small parts. Not for children under 3 years.



"Ne concerne que les USA"




Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
¡Por favor, guarde estas instrucciones para el futuro!  
Belangrijke documenten, bewaar deze zorgvuldig!




Abbildungen können vom Original abweichen.  
Product may differ from image shown.  
Les illustrations peuvent différer de l'original.  
Las ilustraciones pueden diferir del original.  
Afbeeldingen kunnen verschillen van het werkelijke artikel.


1









































8











9
















30 22 8842



30 22 8862




30 80 0596




30 22 8892




30 07 6703



30 07 6693



30 46 7222



30 51 1363



30 46 7392




30 51 9490



30 07 4633




3x 30 07 4573



30 07 4523



30 07 6723



2x 30 61 1292



2x 30 25 7510



3x 30 28 6720



30 07 6753



30 22 9202



30 07 4393



30 07 6713




30 80 0316



30 22 8772




30 28 8830



30 22 8782



30 07 4473



30 07 6743




30 07 4493




30 07 4643



30 46 6560



30 51 1463



30 51 9450



2x 30 22 8792



30 06 8463



2x 30 07 4603



30 46 6570



30 25 8580



30 22 1290



30 07 4033



30 80 0326



30 20 6900



30 25 8570





30 25 6602



3x 30 22 8732



30 65 8822



2x 30 07 4213



30 22 9302



30 22 9312



2x 30 07 4623



30 07 6733



30 64 5806



30 07 7833



30 24 8370



2x 30 20 6880



2x 30 07 4243



2x 30 09 2110



2x 30 24 1583



30 07 4483



30 25 6820



30 25 6730



4x 30 05 8550



30 22 8812



8x 30 03 2920



30 07 6763



30 22 8742




30 22 8752




2x 30 23 3752




4x 30 03 5902




16x 30 03 6600



36x 30 09 6900



30 61 1312



30 51 5562




6x 30 25 0740



6x 30 25 0720



6x 30 25 0000



6x 30 25 5502



6x 30 03 5582




6x 30 03 5602



12x 30 04 0703



5x 30 25 8720



5x 30 25 2810

UK-Importer:  
Playmobil UK Ltd.  
Regency House  
1 Miles Gray Road  
Basildon  
Essex  
SS14 3RW  
UK



Serviceadressen finden Sie in allen  
PLAYMOBIL-Prospekten

Addresses of Customer Service Depart-  
ments are shown in all PLAYMOBIL  
catalogues

L'adresse du service consommateurs  
est indiquée dans tous les catalogues  
PLAYMOBIL

Troverete gli indirizzi dei centri di  
assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u  
het adres van onze klantendienst.

Las Direcciones de los Departamentos  
de Servicio al Consumidor se encuentran  
en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης  
Καταναλωτών PLAYMOBIL βρίσκεται σε  
όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēēl



# Princess



70455



70452



70447



70450



70448



70453



70451



70454



70449

© 2020 geobra Brandstätter Stiftung & Co. KG  
Brandstätterstr. 2-10 • 90513 Zirndorf, Germany  
No. 30 81 3795 06.22

