

playmobil®

HISTORY



70465



# WARNING: CHOKING HAZARD






Small parts. Not for children under 3 years.





”Ne concerne que les USA“

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
¡Por favor, guarde estas instrucciones para el futuro!  
Belangrijke documenten, bewaar deze zorgvuldig!





Abbildungen können vom Original abweichen.  
Product may differ from image shown.  
Les illustrations peuvent différer de l'original.  
Las ilustraciones pueden diferir del original.  
Afbeeldingen kunnen verschillen van het werkelijke artikel.



1










4x













6










7



















1



2




30 61 1382



30 51 3580

30 03 8612



30 09 1720

1




30 25 8720



30 22 5770

30 25 5053

2




30 22 5790

30 22 5780



30 51 3502










30 67 3362

3x


30 20 3670



30 20 5000




30 80 1216



3x 30 07 7083



30 07 7073



30 65 8822



15x 30 02 0164




2x 30 66 7780



30 20 6840



4x 30 20 6850



2x 30 07 7063



2x 30 07 7103

30 07 7093



2x 30 07 7113



30 25 8932



5x 30 20 6860



2x 30 23 4662



3x 30 20 6880



9x 30 20 6900



2x 30 22 5912



3x 30 25 6163



2x 30 06 0522



30 20 5120



30 27 4140



30 89 5452



5x 30 02 2312



30 25 5922



30 26 6110



30 29 7300



3x 30 05 8550



30 89 5502



3x 30 07 7153



30 21 4273



5x 30 07 7123



30 64 5855



3x 35 04 2882



2x 30 88 1222



2x 30 22 6242



4x 30 27 4150



2x 30 08 5362



35 04 2872




30 25 0543



2x 30 26 8630



2x 30 25 8440



79x 30 09 6900




32x 30 03 6600



30 60 6562



30 51 4592



30 51 6832



Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL cataloghi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-beel



# HISTORY



70466



70465



70471



70470



70468



70469



70467

