

playmobil®

STUNT
SHOW



70554



WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service Depart-
ments are shown in all PLAYMOBIL
catalogues

L'adresse du service consommateurs
est indiquée dans tous les catalogues
PLAYMOBIL

Troverete gli indirizzi dei centri di
assistenza in tutti i cataloghi PLAYMOBIL


In alle PLAYMOBIL catalogi vindt u
het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran
en todos los catálogos PLAYMOBIL


Η διεύθυνση του Γραφείου Εξυπηρέτησης
Καταναλωτών PLAYMOBIL βρίσκεται σε
όλους τους καταλόγους PLAYMOBIL.

pronounced: plāymō-bēēl

1



30 80 3106



30 02 2582




30 02 2492

30 02 2592

30 02 2472

2



30 04 8472


30 21 7172

30 08 0163

30 27 1060

30 08 0173

3



30 89 4680

30 09 9000

4

2x


30 82 6274



30 08 0153

2x

30 82 6284



30 08 0143



30 07 0712

30 25 6163

30 64 3965

30 08 4462

30 28 4490

30 08 0133

30 00 7904

2

30 20 1482



oder
or
ou

2



2x

30 25 6163



30 02 2682



30 08 3852



30 08 3862



30 08 3872



30 08 3882



70551



70552



70553



70554



70544



70550



70549

