

30 03 5803

30 08 7963



30 29 7120

30 09 8300

ASSEMBLY INSTRUCTION

30 03 1315



30 02 2682

30 22 0510



30 03 2352

30 08 8732

30 03 1325



30 02 2374

30 08 3693



30 08 3693

30 02 5714



30 51 6012

30 08 3703



30 05 4122

30 21 5853



30 51 5593



71500



71504



71502



71499



71503

NEU ab März  
 NEW in March  
 NOUVEAU en mars  
 NUEVO en marzo  
 2024



©2023 geobra Brandstätter Stiftung & Co. KG • Brandstätterstr. 2-10  
 90513 Zirndorf, Germany • No. 30 82 1476 08.23



FR DONNEZ OU RECYCLEZ  
 ASSOCIATION MARGASIN OU LIVRAISON DÉCHÈTRIE  
 Adresses sur quefairemesdechets.fr

playmobil®

Princess Magic



71446





# WARNING:

## CHOKING HAZARD

Contains a small ball and small parts.  
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
¡Por favor, guarde estas instrucciones para el futuro!  
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.  
Product may differ from image shown.  
Les illustrations peuvent différer de l'original.  
Las ilustraciones pueden diferir del original.  
Afbeeldingen kunnen verschillen van het werkelijke artikel.

Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēē

**UK-Importer:**  
**Playmobil UK Ltd.**  
**Regency House**  
**1 Miles Gray Road**  
**Basildon**  
**Essex**  
**SS14 3RW**  
**UK**



30 06 5462




30 11 5620


30 03 5154




30 14 8092



30 62 0049



30 63 1594




30 62 0039




30 05 7713



30 21 0813



30 82 1356



30 82 1366

1



2

